

For sensorcontrollers SC1eS, SC2eP, SC8eS, Software Version 2.96.*



- ① Install the software by executing `TGuard_296-n.exe` in the distribution CD ROM's root directory.
- ② Activate your personal license: **Thermoguard Configuration=>Licensing=>Reload *.lic file**. You'll find your specific license file in the CD's subdirectory `_License`.
- ③
 - a. Connect sensor(s) to the sensorcontroller ("SC") according to the wiring scheme printed on the device.
 - b. Connect the SC to your local network with a standard RJ45 patch cable.
 - c. If SC does *not* support PoE (Power over Ethernet):
Connect the SC to power using the power adapter
US-sites: check if the adapter supports 110V AC.
- ④ Now, the SC will receive his own unique IP address via **Thermoguard Configuration=>Scan local network** (as agreed with your IT department):
Select the new entry showing IP address "0.0.0.0" and enter your desired IP address in the yellow input field. Confirm by clicking the **Assign IP address (ALT+g)** button, which will be enabled if the address has been entered in a correct format.
You must start the Thermoguard program with administrator privileges to assign the IP address.
Additionally be aware that firewall rules may block the network communication.
- ⑤ Now enter the settings for each sensor under tab **Sensor configuration**:
Insert, doubleclick on new entry => then go to **Basic settings=>Use IP address** and enter the IP address you assigned in step ④.
Check the correct entry of the **Source** setting too.

Ready. Now your sensorcontroller can be polled by the software.

SC2e/SC8eS: Each time after an additional new sensor has been attached to the sensorcontroller, the sensorcontroller must be powered off and on!

For details please refer to the *system manual* located on the CD.

We wish success in setting up *Thermoguard*.

Any questions? => info@thermoguard.de